

1



2



Ensure the 2 black loops are threaded through the red loops.

Note : One black loop will be twisted under the protective sleeve. This is normal.

6



Now pull both black loops and tighten the strap on the handlebars.

Use the tie down strap with the hook through each black loop and fix to a strong point in the van or trailer. Tighten the tie down straps until the forks are compressed by 20 - 30mm. The tie down straps should pull UP towards you.

The bike is ready to be transported.

Ideal distance between tie down straps on the floor is 500mm each side from wheel.

3




Now place the strap across the tank

4



Then place the red loops OVER the handlebar

5



Ensure the black loop is BETWEEN the handlebar and brake lever